Application Note 32 1(3)

Cross-axis Compensation



OBJECTIVE

This document describes how to measure and calculate the cross-axis sensitivity of an inclinometer. The second part of this is document describes how to compensate for the cross-axis error in applications.

The cross-axis definition is valid for all of VTI's inclinometers and accelerometers. The cross-axis compensation can be applied for dual axis inclinometers such as the SCA100T series.

DESCRIPTION

The cross-axis sensitivity shows how much perpendicular acceleration or inclination is coupled to the signal. This error is caused by a mounting error of the sensor element and the actual component. In applications that need accurate information about the plane's tilt positioning, the cross-axis error may cause inaccuracy.

Cross-axis sensitivity is defined bellow as follows:

$$CrSens = \frac{\sqrt{S_Y^2 + S_Z^2}}{S_Y} \cdot 100\% \tag{1}$$

where S_X is the measured sensitivity in measuring direction, S_Y and S_Z are the measured sensitivities in cross-axis directions. Sensitivities used in cross-axis calculation should be in the [V/g] unit.

The measurement and calculation of SCA100T-D02 cross-axis sensitivity is used as an example. SCA100T X-channel measuring direction and cross-axis directions for X-channel are presented in figure 1.




Figure 1. SCA100T X-channel measuring direction.

Sensitivities in equation 1 are measured by tilting the sensor equally in two positions (*tilt1* and *tilt2*). Tilt position should be selected so that the sensor output is still within measuring range.



Application Note 32 2(3)

Sensor output is measured in tilt positions. Sensitivities are calculated as follows:

$$S = \frac{Vout_{iilt1} - Vout_{tilt2}}{\sin(tilt1) + \sin(tilt2)} = \frac{Vout_{tilt1} - Vout_{tilt2}}{2 \cdot \sin(tilt1)}$$
(2)

where S is the sensitivity in [V/g], $Vout_{tilt1}$ is the measured output in tilt1 position, $Vout_{tilt2}$ is the measured output in tilt2 position. The tilt in equation 2 is the amount of tilt angle in degrees.



If ±90° tilt positions are used the equation 2 is reduced to

$$S = \frac{Vout_{tilt1} - Vout_{tilt2}}{\sin(90^{\circ}) + \sin(90^{\circ})} = \frac{Vout_{tilt1} - Vout_{tilt2}}{1 + 1} = \frac{Vout_{tilt1} - Vout_{tilt2}}{2g}$$
(3)

Figures 2, 3 and 4 present the measuring positions for X-channel cross-axis sensitivity. Measure X-CHANNEL OUTPUT in each position in figures 2, 3 and 4.

Sensitivity in measurement direction (X-axis) is measured in positions presented in figure 2.




Figure 2. Measure X-channel output for X-axis sensitivity (positions for S_X).

Cross sensitivity in Y-axis direction is measured in positions presented in figure 3.




Figure 3. Measure X-channel output for Y-axis cross sensitivity (positions for S_Y).

Cross sensitivity in Z-axis direction is measured in positions presented in figure 4.




Figure 4. Measure X-channel output for Z-axis cross sensitivity (positions for S_Z).



Application Note 32 3(3)

SOLUTION

The inaccuracy due to cross-axis sensitivity in plane positioning can be compensate for in the application.

In order to compensate for the X-axis cross-axis error, the following measurements need to be made:

- 1. Measure X-channel sensitivity in Y-axis direction (figure 5 tilt1 and tilt2 positions).
- 2. Measure Y-channel sensitivity in Y-axis direction (figure 5 tilt1 and tilt2 positions).
- 3. Calculate X-channel sensitivity in Y-axis direction (equation 2).
- 4. Calculate Y-channel sensitivity in Y-axis direction (equation 2).

All sensitivities measured above need to be in [V/g] units. The two tilt positions needed for the measurements are presented below in figure 5.




Figure 5. Measure X-and Y-channel outputs for X-channel cross-axis error compensation.

The X-channel cross-axis error can be compensated using the following procedure:

- 5. Measure X- and Y-channel outputs.
- 6. Calculate the tilt angle of the plane in to Y-axis direction by using the Y-channel output information and the equation below

$$\alpha_{Y-axis} = a\sin\left(\frac{Vout_{Y-axis} - Voffset_{Y-axis}}{Sens_{Y-axis}}\right)$$
(4)

where α_{Y-axis} is the tilt angle in Y-axis direction, $Vout_{Y-axis}$ is the measured Y-channel output value in [V], $Voffset_{Y-axis}$ is the Y-channel sensitivity value in [V/g].

7. Compensate for the cross-axis error from the measured X-channel output value by using the equation below

$$Xout_{Comp} = Vout_{X-axis} + X_{ch}Sens_{Y-axis} \cdot \sin(\alpha_{Y-dir})$$
(5)

where $Xout_{Comp}$ is the compensated X-channel output value in [V], $Vout_{X-axis}$ is the measured X-channel output value in [V], $X_{ch}Sens_{Y-axis}$ is the X-channel sensitivity in Y-axis direction in [V/g] value (see step 3) and α_{Y-dir} is the tilt angle in Y-axis direction (from equation 4).

By using equation 4, the cross-axis compensated X-channel output can be calculated as presented in equation 6,

$$Xout_{Comp} = Vout_{X-axis} + X_{ch}Sens_{Y-axis} \cdot \frac{Vout_{Y-axis} - Voffset_{Y-axis}}{Sens_{Y-axis}}$$

$$(6)$$

where $Xout_{Comp}$ is the compensated X-channel output value in [V], $Vout_{X-axis}$ is the measured X-channel output value in [V], $X_{ch}Sens_{Y-axis}$ is the X-channel sensitivity in Y-axis direction in [V/g] value (see step 3), $Vout_{Y-axis}$ is the measured Y-channel output value in [V], $Voffset_{Y-axis}$ is the Y-channel offset value in [V] and $Sens_{Y-axis}$ is the Y-channel sensitivity value in [V/g].

12 Sep 2005 VTI Technologies reserves all rights to modify this document without prior notice.

